




Lenovo Yoga-900-13ISK2 SSD Replacement

This guide will show you how to remove the SSD of the Lenovo Yoga-900-13ISK2.

Written By: Nathan Lui



INTRODUCTION

This guide will show you how to remove the SSD of the Lenovo Yoga-900-13ISK2. As an extra precaution, the battery should be removed first before proceeding with the rest of the device.



TOOLS:

- [T6 Torx Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Back Panel





- Flip the laptop so that the back panel is facing up.
- Remove the ten 4.0mm T6 Torx screws from the back of the laptop.

Step 2





- Gently lift the back cover off of the laptop.

Step 3 — Battery




- Push the black battery cable towards the battery to disconnect it.

Step 4




- Remove the six #0 3.8mm Phillips screws from the battery.

Step 5




- Gently lift the battery out of the laptop chassis.

Step 6 — SSD



- Remove the one #0 2.9mm Phillips screw from the SSD.

Step 7



- Gently lift and wiggle the SSD side to side to remove it from the laptop chassis.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 04:49:14 PM.